

# PARTS LIST OF MK.5

## BREECH BLOCK & CASING

2	NGS01BLT020	Nozzle Block
3	NGS01SCW001	Nozzle Screw
6	NGS01NOZ010	Forend, Nozzle
7	NGS01NOZ020	Nozzle Frame
8	NGS01NOZ040	Nozzle Pin
9	P19 O Ring	
10	NGS01SPG012	Nozzle Tension Spring
11	NGS01NOZ050	Nozzle Tension Spring Pin
12	NGS01NOZ030	Nozzle Valve
13	NGS01SPG001	Nozzle Valve Spring
14	NGS01SPG001	Ruruning Spring
15	NGS03BLT101	Charging Handle, MK.5
16	NGS02URV001	Casing (Conditional Offer)
17	NGS02SPG020	Returning Spring Housing Cushion
18	NGS01SPG011	Returning Spring Housing Cushion Guide
19	NGS01SPG010	Returning Spring Cap

(組合物) プリーチブロックキャリアセット: 1, 4, 5

1	NGS02BLT010	MK.5 Breech Block
4	NGS01BLT030	Breech Block Reinforced Plate
5	NGS01KNP001	Breech Block Reinforced Plate Pin

(組合物) 木製ピストルグリップセット: 20, 21

20	NGS02URV021	Pistol Grip
21	M8 Hex Socket Head Cap Screws	

(組合物) NGS01NOZ001 Nozzle(JP); セット: 6, 7, 8, 9, 10, 11, 12, 13

## MISC

1	NGS02STK070	Sling Swivel Base Screw X2
2	NGS02STK060	Sling Swivel Base
3	NGS02STK050	Sling Swivel
4	NGS02STK040	Stock End Plate Screw X2
5	NGS02SBP001	Stock End Plate Assembly
6	NGS02STK030	Stock Piece (Conditional Offer)
7	NGS02STK010	NGS02STK060 Stock Base M10 Hex Socket Head Cap Screws

## BARREL

14	INNGSBRL180	Inner Barrel 180mm
15		Hop Up Adjust Wheel Spacer
16	NGS01HOP010	Hop Up Adjust Wheel
17	NGS01HOP02	Left Hop Up Chamber0
18	NGS01HOP030	Right Hop Up Chamber
19	NGS01HOP040	Hop Up Arm
20		JP MK.5 3X1.5 Hop Up Rubber Nub
21	NGS01HOP060	Hop Up Rubber
22		M2.5 Phillips Screw X2
23	NGS02HGD001	Barrel Nut
24	NGS02FST010	Front Sight Blade
25	NGS02FST041	Front Sight Screw
26	NGS02FST020	Front Sight Base
27	NGS02FST030	Front Sight Guard
28		3M Knurled Pin
29	NGS02FST020	Front Sight Guard Screw

(組合物) アウターバレルセット11, 12, 13

11	NGS02BRL010	MK.5 Outer Barrel
12	NGS02BRL020	Outer Barrel Base
13		MK.5 Outer Barrel Pin


(組合物) 木製フォアグリップセット: 30, 31, 32 (Conditional Offer)

30	NGS02FPR001	Foregrip Fix Ring
31	NGS02FGP010	Foregrip
32		M8 Hex Socket Head Cap Screws

## MAGAZINE HOUSING

1	NGS02LRV010	MK.5 Magazine Housing
2	NGS01SPG004	Magazine Catch Spring (Blue)
3	NGS03LRV020	Magazine Catch (Blue)
4		M5 Washer
5	SCW3/16-32_SR	3/16-32 Slotted Round Head Screw

6	NGS03LRV030	Retainer (Blue)
7	NGS03LRV002	Housing Plunger (Blue)
8		PN2.5x19_CTP 2.5x19 Split Pin
9	NGS01SPG005	Housing Plunger Spring
10	NGS03LRV040	Barrel Nut Catch (Blue)



## TRIGGER

20	NGS01URV020	Sear
21	NGS01SPG008	Tripping Lever Pawl
22	NGS01TRG020	Trigger Pin
23		PN5.5x26 Sear Pin
24	NGS01SPG003	Trigger Spring
25	NGS03TRG010	Trigger(Blue)
26		3x9mm Roll Pin
27		2.5x19 Split Pin
28	NGS01FSR001	Change Lever
29	NGS01URV030	Tripping Lever

## STRIKER MECHANISM

8	NGS01URV011	Trigger Mechanism Cover
15	NGS01SPG007	Fire Pin Case Return Spring
16	NGS01FPN040	Fire Pin Base
17	NGS01FPN050	Impact Block
18	NGC01SPG008	Impact Block Base Spring X2
19	NGS01FPN080	Fire Pin Base Screw X2

(組合物)バルブノッカーカバーセット: 9, 10  
 9 NGS01FPN060 Fire Pin Cover Screw X2  
 10 NGS01FPN010 Fire Pin Cover

(組合物)バルブノッカーセット: 11, 12, 13, 14  
 11 NGS01FPN020 Fire Pin  
 12 NGS01SPG006 Fire Pin Spring  
 13 1.5x6m Roll Pin  
 14 NGS01FPN030 Fire Pin Case